




## **Short Guide 1/3**






## LOAD PAPER IN TRAY 1 REFILL

- 1. Pull out tray 1.
- Load the paper into tray 1 (not higher than ▼).
- **3.** If you load special paper, change the paper selection.



#### **CHANGE THE PAPER SELECTION**

- 1. Touch PAPER in the basic screen.
- 2. Touch TRAY 1.
- 3. Touch CHANGE TRAY SETTINGS.



- 4. Touch the desired paper selection.
- 5. Touch OK.



6. Touch OK.



### **Short Guide 2/3**

#### **BASIC FUNCTIONS Z00M** Different values for X Position the original(s) Change zoom manually and Y (distortion) Touch **ZOOM** in the basic screen. Automatically Ready to copy. reduce/enlarge Touch the desired function. original size to paper Original Setting Bensits/ Application size Touch **OK**. Press the **START** key. Keep original size User defined Little bit smaller zoom 400.0% than original size (values can be 200.0% (value can be changed\*) changed\*) 50.0% Y M C K 13/ 1/2006 18:39 Met ry 997. Preset zoom values \*refer to User Manual for Copy Operations

# APPLICATION FUNCTIONS IMAGE ADJUSTMENT


**1.** Position the original(s).

**DUPLEX** 

- 2. Touch **DUPLEX/COMBINE** in the basic screen.
- **3.** Touch the desired function.



- 4. Touch OK.
- **5.** Press the **START** key.



- 1. Position the original(s).
- 2. Touch **IMAGE ADJUST** in the application screen.



**3.** Touch the desired function.




- 1. Touch OK.
- **5.** Press the **START** key.



## BASIC FUNCTIONS QUALITY/DENSITY

- 1. Position the original(s).
- 2. Touch QUALITY/DENSITY.
- Select the type of your original.
- I. Touch the desired function.
- 5. Touch OK.
- 6. Press the START key.



### **FINISHING FUNCTIONS**


FINISHING (only with Finisher)

- 1. Position the original(s).
- 2. Touch **FINISHING** in the basic screen.
- Touch the desired function.\*



- 4. Touch OK.
- 5. Press the START key.

\*available functions depend on machine/finisher



### **CREATE A BOOKLET**

- **1.** Position the original(s).
- 2. Touch **FINISHING** in the basic screen.
- Touch FOLD/BIND.



4. Touch the desired function.\*



- 5. Touch OK.
- 6. Touch OK.
- **7.** Press the **START** key.

\*available functions depend on machine/finisher



## **Short Guide 3/3**

Fax / Scan

(17/€

### **FAX OPERATIONS**

### SEND A FAX (only with Fax option)

- **1.** Position the original(s).
- 2. Press the FAX/SCAN key on the panel.
- Touch **DIRECT INPUT**.
- Touch **FAX**.
- Enter the fax number.
- Touch **OK**.
- 7. Press the START key.



(1)/€



### **BOX OPERATIONS** SAVE IN USER BOX

- **1.** Position the original(s).
- Touch **SAVE IN USER BOX** in the application screen.



- Touch USER BOX.
- Select the desired box.
- Touch **OK**.



- Enter a document name.
- Touch **OK**.
- Touch **OK**.
- 9. Press the **START** key.

### PRINT FROM USER BOX

- 1. Press the **BOX** key on the panel.
- Choose between Personal, Public or System User Box.



- Touch the desired box. Input a password if required.
- Touch the desired document.



- Touch **PRINT**.
- Specify the settings.
- 7. Press the START key.

### **NETWORK SCAN OPERATIONS**

### SENDING DATA TO MULTIPLE DESTINATIONS

- 1. Position the original(s).
- 2. Press the FAX/SCAN key on the panel.
- Touch ADDRESS BOOK.
- Touch the desired index key and highlight a destina-
- Repeat step 4 until all desired destinations are high-
- 6. Press the START key.





### SCAN TO E-MAIL (Direct input)

1. Position the original(s).

**User Box** 

 $\Diamond$ 

- Press the FAX/SCAN key on the panel.
- Touch **DIRECT INPUT**.
- Touch E-MAIL.



**5.** Enter the destination address.



- Touch OK.
- **7.** Press the **START** key.

### SEARCH AN E-MAIL ADDRESS

- 1. Press the **FAX/SCAN** key on the panel.
- Touch ADDRESS BOOK.
- 3. Touch SEARCH.

Fax / Scan

(1)/€



- Touch **DETAIL SEARCH**.
- Touch NAME or ADDRESS



- Input a keyword.
- Touch OK.
- Touch OK.
- 9. Touch CLOSE.

